BRT-03 Installation Instructions Pintail and ES100 - 12 gauge shotguns

WARNING: UNLOAD WEAPON BEFORE ATTEMPTING TO INSTALL ANY COMPONENT!!!

- 1. Remove the barrel, bolt assembly, and trigger group from receiver.
- 2. Remove the recoil pad from the stock.
- 3. Remove the stock locking nut and note the position of the offset spacer before sliding off the stock.
- 4. Place receiver in a padded vise.
- 5. Using a propane torch, heat the factory tube approximately one inch away from the receiver for 1 minute. While heating, unscrew the factory tube from the receiver using a pipe wrench or locking pliers.
- 6. Clean the receiver threads with solvent and brush.
- 7. Screw the SURE CYCLE system into the receiver by hand. DO NOT USE THREADLOCKER. Lightly tighten the tube using a 11/16" wrench on the flats milled into the threaded plug. DO NOT put a wrench or pliers on the stainless tube while tightening or removing the SURE CYCLE. ONLY USE A DRIFT PIN OR 11/16" WRENCH ON THE MILLED FLATS.
- 8. Slide the butt stock over the tube and align the threaded end through the hole in the offset spacer.
- 9. Firmly tighten the butt stock locknut and attach butt pad.
- 10. Reassemble the trigger group, bolt assembly, and barrel.

The SURE CYCLE system requires no lubrication. **DO NOT** use any type of oil, grease or other lubricant in the system. If necessary, disassemble the SURE CYCLE and clean the components with a mild detergent and hot water. Dry thoroughly before assembling the system.

You are now ready to enjoy your new SURE CYCLE system.