

Shotgun *Magazine Tube* Extension Kit

REMEXT Installation Instructions

Remington 870, 1100, 11-87, Versa Max, V3 and Similar 12ga. Shotguns

WARNING: UNLOAD AND PROPERLY CLEAR THE WEAPON BEFORE ATTEMPTING TO INSTALL ANY COMPONENT!!!

- 1. Remove the magazine cap from the magazine tube.
- Early Models Remove the magazine spring retainer by gently prying it out with a flat screwdriver.
 Later Models Depress the retainer and rotate it to align its grooves with the detents on the magazine tube. Carefully allow the retainer to be pushed out of the tube. The magazine retainer is under tension. Use caution when removing.
- 3. Remove the factory magazine spring, follower and 3 shot plug from the tube.
- 4. Later models of the Remington 870, 1100, 11-87, Versa Max and V3 will need to have the magazine spring retainer detents removed. This can be accomplished by either drilling them out using a 1/4" drill bit or by grinding away with a Dremel® or similar tool.
- 5. Thoroughly clean the interior of the magazine tube and LIGHTLY coat it with any lubricant.
- 6. Slide the red follower into the factory tube with the solid end facing the receiver.
- 7. Slide the black follower into the extension tube with the solid end facing away from the threaded end of the tube. Insert one end of the new magazine spring into the extension tube and the other end into the factory tube.
- 8. While guiding the spring into both tubes, carefully thread the collar of the extension tube onto the factory tube. You will have to guide the spring coils into the tube until the retainer contacts it. Thread the collar partially onto the magazine tube, but not touching the forearm. While holding the collar, unscrew the extension tube a few turns. Tighten the collar to seat the forend and barrel to the receiver. Now screw the extension tube into the collar until it contacts the factory magazine tube. DO NOT USE A WRENCH FOR THIS OPERATION HAND TIGHTENING THE EXTENSION TUBE INTO THE COLLAR IS SUFFICIENT
- 9. Remove the nut from the barrel clamp assembly. Fit the barrel clamp, with the smaller radius side clamping onto the barrel, approximately three inches from the end of the extension tube. Mate the other half of the clamp to it and tighten the nut. The use of rubber tape on the inside surfaces of the barrel clamp will help decrease the chances of slipping or scratching.

You are now ready to enjoy your new SURE CYCLE extended magazine tube.



1101 Mason Circle Drive Pevely MO 63070 636-224-2708